



---

## Warning Light System

### Product Images

---



### Description

---

#### FEATURES

- Suitable for use with Bristol Maid Controlled Drug cabinets
- Provides a visual indication when the cabinet is open
- LED illuminates...
  - Green when the door is closed
  - Red when the door is open
  - Flashes red when open for 2 ½ minutes
- Operates using a door activated micro-switch connected to a 12v DC LED lighting / warning system (model dependent) with volt-free contact to allow connection to light / nurse call systems. Requires 100v - 240v ~, 50Hz - 60Hz, 0.3A Mains supply. Supplied fitted with a UK 3 pin plug. CE marked & conforms to the low voltage directives 73/23/EEC & 89/336/EC
- Lighting transformer housing adds 105mm to the overall height

| Code  | Description                                                                                                              | Weight |
|-------|--------------------------------------------------------------------------------------------------------------------------|--------|
| CD910 | LED Lighting / Warning System - Compatible with cabinets: CD005, CD010, CD110, CD015, CD115, CD020, CD120, CD025 & CD125 | -      |
| CD911 | LED Lighting / Warning System - Compatible with cabinets: CD030, CD130, CD035 & CD135                                    | -      |
| CD913 | LED Lighting / Warning System - Compatible with cabinets: CD045 & CD145                                                  | -      |