



Warning Light System

Product Images



Description

FEATURES

- Suitable for use with Bristol Maid Controlled Drug cabinets
- Provides a visual indication when the cabinet is open
- LED illuminates...
 - Green when the door is closed
 - Red when the door is open
 - Flashes red when open for 2 ½ minutes
- Operates using a door activated micro-switch connected to a 12v DC LED lighting / warning system (model dependent) with volt-free contact to allow connection to light / nurse call systems. Requires 100v - 240v ~, 50Hz -60Hz, 0.3A Mains supply. Supplied fitted with a UK 3 pin plug. CE marked & conforms to the low voltage directives 73/23/EEC & 89/336/EC
- Lighting transformer housing adds 105mm to the overall height

Code	Description	Weight
CD910	LED Lighting / Warning System - Compatible with cabinets: CD005, CD010, CD110, CD015, CD115, CD020, CD120, CD025 & CD125	-
CD911	LED Lighting / Warning System - Compatible with cabinets: CD030, CD130, CD035 & CD135	-
CD913	LED Lighting / Warning System - Compatible with cabinets: CD045 & CD145	-